

Fiddes Hard Wax Oil

PREPARATION	Ensure all surfaces are clean, dry, and free from any previous finish. Sand the substrate with a fine 150 grade sanding paper or 150 grit sanding disk, removing all traces of dust.
APPLICATION	Ensure all areas to be coated are extremely well ventilated during and after application. Always test on a small area prior to initial application. No primer required. Maximum 2 coats recommended. Apply at room temperature. Fiddes Hard Wax Oil is formulated for application directly, and does not require thinning.
FIRST COAT	Stir contents thoroughly before and during use, and apply in a warm, well ventilated room. Apply THINLY using Fiddes Floor Oil Brush or a good quality bristle or synthetic brush, and lay EVENLY, following the direction of the grain. Leave to dry 4-6 hours in warm, dry well ventilated conditions, or preferably overnight.
SECOND COAT	Apply as first coat, THINLY, allowing good ventilation. Leave to dry 4-6 hours in warm, dry well ventilated conditions, or preferably overnight. Clean applicator with White Spirit. When the surface area is completely dry, a light buff will further enhance the sheen level.
RENOVATION	To renovate previous application of Fiddes Hard Wax Oil, lightly sand area with 150 grit sandpaper, and re-apply sparingly.
COVERAGE	A single application will cover approximately 20-24 square metres per litre, depending on the density of the substrate.